

XFL006-1 INSTRUCTION MANUAL

For 37-70" TV


If you have any questions along the way, just give us a call 1-800-460-0956 or mail to customerservice@x-mount.com. We're ready to help!



$oldsymbol{\Delta}$ CAUTION: PLEASE READ ENTIRE MANUAL PRIOR TO USE AND SAVE THESE INSTRUCTIONS.

Before getting started, let's check below lists to make sure it is just right for you!

Check your TV VESA is within Min and Max size



No? This mount is NOT compatible.

Yes? Perfect!

Does your TV (including accessories) weigh MORE than 132 lbs. (60 kg)?




No? Perfect – you may continue.

Yes? This mount is NOT compatible.

A CAUTION: DO NOT exceed the maximum weight indicated. This mounting system is intended for use only with the maximum weights indicated. Use with products heavier than the maximum weights indicated may result in collapse of the mount and its accessories, causing possible injury.

What is your wall made of?



Drywall with wood studs?



Solid concrete




Unsure? Call Customer Service: 1-800-460-0956

Do you have all the tools needed? (Not included)





Measure






driver















Hammer


Caution

- This product is designed for use in wood stud, solid concrete walls DO NOT install into drywall alone
- The wall must be capable of supporting five times the weight of the TV and mount itself
- Do not use this product for any purpose not explicitly specified by manufacturer
- Manufacturer is not responsible for damage or injury caused by incorrect assembly or use

Product dimensions:







STEP 1 Attach Brackets to TV


Parts and Hardware


🛕 WARNING: This product contains small items that could be a choking hazard if swallowed. Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; contact **Customer Service.**


Never use damaged parts!



NOTE: Not all hardware included will be used.








STEP 2 Attach Wall Plate to Wall




For wood stud installation, follow STEP 2A on PAGE 9





For concrete installation, follow STEP 2B on PAGE 12






STEP 2A Wood Stud Installation









CAUTION: To avoid potential personal injury or property damage:

All 4 lag bolts MUST BE firmly tightened to prevent unwanted movement of the wall plate assembly. Ensure the wall plate assembly is securely fastened to the wall before continuing on to the next step.





Go to Step 3 on PAGE 14.


STEP 2B Solid Conrete Wall Installation













A CAUTION: To avoid potential personal injury or property damage:


All 4 lag bolts MUST BE firmly tightened to prevent unwanted movement of the wall plate assembly. Ensure the wall plate assembly is securely fastened to the wall before continuing on to the next step.






STEP 3 Hang and Secure TV to Wall Plate

Before hanging TV, please conduct "wall plate installation integrity test" first.





Take Down the TV from the Mount

